

Step 5.

Keeping the Cartridge in its original vertical position with the open end facing up, flick the side of the Cartridge several times.

The reagent powder should be settled evenly on the clear bottom window.

