

CLINIQUE

Belk Clinique Derm Tower Topper Assembly Instructions



1 Arrives flat.



2 Prefold all scores. Squeeze into cube shape.



3 Fold in both flaps without double sided tape on back. Make sure the flaps are set straight.



4 Remove tape liner from one flap.



- 5** Press flap down making sure it is lined up perfectly as tape is permanent stick.



- 6** Line up other side.



- 7** Repeat removing the tape liner on this flap.



- 8** Press firmly to adhere tape.



- 9** Turn box over and press firmly on the inside to secure tape.



- 10** Place assembled box on top of Clinique Derm fixture.