

Concept		Measurement Specification Worksheet			NMcGowan	
		S11CLG101				
Senior Project	Style	S11CLG101	Folder Description	Sleeveless flare blouse		
None			Folder Status By			
None	Fabric Content 1	59% Cotton, 37% acetate, 4% viscose	Date Folder Created	12 JAN 2011 03:34 PM		
Spring 2012	Fabric Content 2		Date Folder Modified	31 JAN 2011 05:48 PM		

219 Bust/ Chest- 1" Below Armhole Lay garment flat with front facing you. Measure from 1" below armhole straight across side seam to side seam.		148 Back Neck Drop HPS Lay garment flat with front facing you. Place ruler horizontally at join seam of neck and shoulder to designate straight line. Measure from the center straight down to the edge/ join seam of the center back.	
---	--	--	--

147 Front Neck Drop HPS Lay garment flat with front facing you. Place ruler horizontally at join seam of neck and shoulder to designate straight line. Measure from the center straight down to the edge/ join seam of the center front.		150 Neck Width Lay garment flat with front facing you. Measure from neck seam/ edge across to opposite neck seam/ edge.	
--	--	---	--

Concept		Measurement Specification Worksheet			NMcGowan	
		S11CLG101				
Senior Project	Style	S11CLG101	Folder Description	Sleeveless flare blouse		
None			Folder Status By			
None	Fabric Content 1	59% Cotton, 37% acetate, 4% viscose	Date Folder Created	12 JAN 2011 03:34 PM		
Spring 2012	Fabric Content 2		Date Folder Modified	31 JAN 2011 05:48 PM		

230 Armhole Circumference Measure from top to bottom of armhole following the seam contour.			
---	--	--	--

227 Sweep along edge Measure at bottom of garment following the contour of hem.			
---	--	--	--