

Assembling and finishing

1st: Assemble profiles with a twist using a square dowel through



2nd: Attach connecting pieces to slotted profiles



3rd: Connect slotted profiles with the aid of two screws



4th: Glue balsa struts between profiles for stability

5th: Wrap blades in several layers of baking paper using diluted wood glue and trim excess paper

6th: Leave to dry or use a handdrier for a quicker result