

## Swatches

---



50% Polyester/100% Cotton Blend



Interlining



Piping

## Interlining Assembly

---

### Step One

Cut two pieces of fabric. These must be 13"x13" in order to create the desired 12"x12" when accounting for seam allowance.

### Step Two

Sew the two pieces together with a ¼" seam. Leave a few inches unsewn.

### Step Three

Fill the interlining with Mountain Mist Pillowloft.

### Step Four

Sew the opening shut from the running stitch.

## Throw Pillow Cover Assembly

---

### Step One

Cut two pieces of fabric. These must be 13"x13" in order to create the desired 12"x12" when accounting for seam allowance

### Step Two

Fold the fabric in half with the finished sides facing inwards and the unfinished sides facing out.

### Step Three

Sew the two fabrics together leaving a ½" seam allowance. Reinforce the seams by backstitching.

### Step Four

Flip the garment inside out again (with the "wrong" side facing out) and iron the seam open.

### Step Five

Place the zipper face down on the open seam and use the zipper foot on the sewing machine in order to attach the zipper.

### Step Six

Pin the piping to the outside edges of the pillow, leaving a small gap of space at the ends of the piping.



**Step Seven**

Sew the piping to the pillow, creating a V-shape with the gap of piping left at the edge.

**Step Eight**

Place the second layer of fabric over the piping and sew together.

**Step Nine**

Turn the fabric back the “right” side and sew the three remaining (zipperless) sides together. Now you have the cover.