



## CLIENT PRE-INSTALL CHECKLIST

**To ensure a smooth and efficient install, please complete the following steps before our arrival:**

- Driveway should be clear of any vehicles so our trucks may pull in to unload stone
- Yard where turf is being installed should be clear of furniture, toys, or any other items
- Please be sure all dog waste is removed from the yard prior to excavation in order to avoid an additional fee for the cleaning of our equipment and tools
- There is a risk that buried cable for internet could be cut during excavation. We can repair it; however, we recommend having your internet provider come out to mark the cable location if you work from home and cannot risk a brief internet outage
- Sprinkler heads should be clearly marked, as well as the sprinkler control box if it's located in the grass where excavation is taking place
- Any invisible fencing should be marked
- Mark any unseen drainage pipes (from downspouts, for example) that you are aware of, as well as drainage grates
- Landscape lighting cables should be marked



### THINGS TO NOTE:

- Stone will be dumped in a pile on your driveway in most cases. We will move it to the project site from there.
- For projects requiring a large amount of stone base, we may need to schedule a stone delivery to your driveway 1-2 days prior to install. We will communicate and coordinate this with you in advance.
- Please make us aware of any other buried lines within the project site.