

pancake art BATTER DISPENSER



Fill shaped pancake cavities
with ease and draw your
own fun pancake shapes

Mix batter right in the bottle
using markings on the side

Gently squeeze bottle to
draw shapes or fill cavities

3 cup capacity

Top-rack dishwasher safe



ITEM NUMBER
01125 (1)

CASE PACK
3