

Twist or push  
bow to activate  
"Kettle Scream."



### SOFT GOODS

"Crinkle" noise  
fabric/paper  
as wrapper.




Fine Mesh  
Soft with  
"tea leaves"



Disks of either liquid (tea, creamer) or granules of "sugar" make cups & pot appear to be full of a dynamic and moving liquid.

White granules of  
"sugar" trapped in disk.



White granules of  
"sugar"



Button that triggers  
Character I.C.

