



The Leica K1.

The K1 can be used in two different ways. Simply pick it up and use as a portable mixer, or attach tripod and stand on the countertop, leaving you free to prepare other parts of your recipe.

The controls are located at your fingertips and are very easy to use. There is a quick on/off control, a turbo boost control, speed control, beater extension control and an ejection device.



A range of attachments are included such as beaters, folding blades, whisks, dough hooks, blenders and a multi-quirl.

