


MAVStepper™ VIG-520 Jumper 2 Reset

Issue

To support Aristocrat Mystery and Progressive game features, Jumper 2 on VIG-520 boards must be set to “F” (Full Duplex) in MAVStepper™ machines. Although this adjustment is currently a part of the manufacturing process, machines that were installed in the field prior to January 01, 2008 may require on-site adjustment.

Resolution


If necessary, VIG-520 boards with Jumper 2 set at *Half Duplex* (H) must be changed to *Full Duplex* (F) in MAVStepper machines.



Procedure

Step	Description
1.	Use needle-nose pliers to remove the shunt from the first and second pins of the Jumper 2 header.
2.	Slide the shunt onto the second and third pins of Jumper 2, nearest to “F.”

Change Jumper 2 to Full Duplex



Questions concerning this Technical Note should be directed to the Aristocrat Technologies, Inc., National Service Support Center at 1-800-482-3723 or ServiceSupport@aristocrat-inc.com