



TOMTOM

BACKPACK MOUNT



TOMTOM

REMOTE CONTROL



TOMTOM

BACKPACK MOUNT

EASY PLACEMENT

Easily clip the camera to any backpack strap to get a stable, first-person shot.

SAFE POSITIONING

Don't worry about the camera being obstructed or damaged by stationary objects.

HIGH-IMPACT FRIENDLY

Focus on the activity while getting the best shot during high-impact activities.

VERSATILE

Try to clip the mount to other items to get unique shots

TOMTOM

REMOTE CONTROL

EASY TAGGING

Tag your highlights when your camera is mounted out-of-reach.

CAMERA CONTROL

Control and monitor your camera status when it is mounted out of reach or sight. The remote control mirrors the two buttons and LEDs on the camera.

SAFE OPERATION

Control your camera when you can't reach it, for example, when it's on the handle bars or the steering wheel.

TOMTOM

BACKPACK MOUNT

TOMTOM

REMOTE CONTROL