



**Step 1**  
Locate the display unit and pre-fold all folds.




**Step 2**  
Fold the back up and the tab inward. Fold the side up and bend over the tab, locking the side into the bottom cutout. Repeat on the other side.






**Step 3**  
Fold the side tabs inward. Bend and fold the front over the tabs and lock into place.




**Step 4**  
Locate the bottom piece and pre-fold all folds.




**Step 5**  
Fold the bottom piece and insert into the bottom of the unit with the tabs downward. Ensure the taller end is at the front of the unit. Push into place.




**Step 6**  
Locate the stair piece and pre-fold all folds. Un-peel the 2 tape coverings.



**Step 7**  
Fold the smaller step inward and press to secure.



**Step 8**  
Fold the larger step inward and press to secure.




**Step 9**  
Locate the 2 pieces of double stick tape and place on the back of the stairs and un-peel.



**Step 10**  
Place the stairs into the unit and press to secure in place.



**Step 11**  
Fold the back down and into the unit.



**Step 12**  
Locate the header.



**Step 13**  
Insert the header into the back of the unit. Press into place.



**Completed Unit**