

HAUNTED LIVING™

HAUNTED LIVING and logo design are trademarks
or registered trademarks of LF, LLC. All rights reserved.

ITEM #5745169
MODEL #61179

12-FT ANIMATED BONE COLLECTOR

Español p. 17

ATTACH YOUR RECEIPT HERE



Thank you for purchasing this Haunted Living product.
Questions, problems or missing parts?
Before returning, contact us on:
888-251-1006, 8 a.m. - 8 p.m., EST, Monday - Sunday or ascsl@lowes.com

XXXXXXX

TABLE OF CONTENTS

Package Contents	3
Safety Information	4
Preparation	4
Assembly Instructions	5
Operating Instructions	15
Care and Maintenance; Troubleshooting.....	16

PACKAGE CONTENTS



PART	DESCRIPTION	QUANTITY
1	Metal Base	1
2	Lower Leg Poles	2
3	Shoes	2
4	Pants	1
5	Upper Leg Poles with Control Box and 5.9V 3A Adapter	2
6	Waist Frame	1
7	Spine Frame	1
8	Hip Hoop	1
9	Shoulder Frame	1
10	Tether	4
11	Left Arm Pole	1

PART	DESCRIPTION	QUANTITY
12	Right Arm Pole	1
13	Shoulder Wire Frame	1
14	Shirt	1
15	Head	1
16	Left Hand with Sack and Skeleton	1
17	Right Hand	1
18	Shovel Upper and Lower Poles	2
19	Shovel Head	1
20	Extension Tube and Extension Bar	5
21	Stakes	8
22	Snap Lock Removal Tool	1

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.

WARNING

- Warning Risk of injury to persons. Read and understand instruction manual before use.
- Warning: CHOKING HAZARD! Small parts. This item is not a toy. For decoration only.
- Do not turn item on until you have completely finished assembly.
- Stay clear of item while operating.
- Do not place item on uneven ground.
- Do not place weight on item while in operation.

PREPARATION

ADULT ASSEMBLY REQUIRED

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.


No tools required for assembly.

Recommend 2 person setup.


Estimated Assembly Time: 25 minutes

ASSEMBLY INSTRUCTIONS

1. Insert and snap lock the LEFT LEG POLE into the METAL BASE.
(Match A to A)



2. Insert and snap lock the RIGHT LEG POLE into the METAL BASE.
(Match A1 to A1)



3. Slide SHOES over LOWER LEG POLES down the METAL BASE.




ASSEMBLY INSTRUCTIONS

4. Place the PANTS with the FRONT label facing forward over the assembled METAL BASE and LOWER LEG POLES.




5. Insert and snap lock the UPPER LEG POLE WITH CONTROL BOX to the left LOWER LEG POLE.

(Match B to B)



6. Insert and snap lock the right UPPER LEG POLE to the right LOWER LEG POLE.


(Match B1 to B1)



ASSEMBLY INSTRUCTIONS

7. Insert and snap lock the WAIST FRAME to the UPPER LEG POLES.

(Match C to C)




8. Insert and snap lock the SPINE FRAME to the WAIST FRAME.

(Match D to D)




9. Tip the assembled METAL BASE, LEGS, WAIST, AND SPINE FRAME against the shipping box to continue assembly. Attach HIP HOOP to WAIST FRAME.




ASSEMBLY INSTRUCTIONS

10. Insert and snap lock the SHOULDER FRAME to the SPINE FRAME.

(Match E to E)




11. Attach the TETHER lines (qt 4) and carabiners to the SHOULDER FRAME.



12. Snap lock the LEFT ARM POLE to the SHOULDER FRAME.



(Match F to F)



ASSEMBLY INSTRUCTIONS


13. Snap lock the RIGHT ARM POLE to the SHOULDER FRAME.

(Match G to G)




14. Insert the SHOULDER WIRE FRAME into the SHOULDER FRAME.

(Match Blue to Blue), (Match Yellow to Yellow).



15. Place SHIRT over SHOULDER WIRE FRAME. Slide left and right arms through sleeves.



ASSEMBLY INSTRUCTIONS

16. Insert and snap lock the HEAD into the SHOULDER FRAME.


(Match H to H)



17. Hook and loop fasten the straps from front of SHIRT around back of neck and secure.



18. Hook and loop fasten the hood to top of HEAD.




ASSEMBLY INSTRUCTIONS


19. Hook and loop fasten the hood to top of each shoulder.



20. Hook and loop fasten the back of the hood.



21. Pull the four TEATHERS out. Two from the shoulder, one from the front, and one from the back.



ASSEMBLY INSTRUCTIONS

22. Insert and snap lock the LEFT HAND WITH SACK AND SKELETON into the LEFT ARM POLE. Hook and loop fasten the sleeve to the LEFT HAND.

(Match I to I)



23. Insert and snap lock the RIGHT HAND into the RIGHT ARM POLE. Hook and loop fasten the sleeve to the RIGHT HAND.

(Match J to J)



24. Raise assembled item from against the shipping box to finish assembly. Two people are recommended.



ASSEMBLY INSTRUCTIONS


25. Insert and snap lock EXTENSION TUBES into METAL BASE. Insert and snap lock EXTENSION BAR into EXTENSION TUBE. Insert and snap lock EXTENSION BAR into SHOVEL HEAD.

(Match N to N), (Match O to O),
(Match P to P), (Match Q to Q)



26. Connect shovel UPPER POLE to RIGHT HAND. Twist to lock. Connect LOWER POLE to UPPER POLE. Twist to lock. Connect LOWER POLE to SHOVEL HEAD. Twist to lock.

(Match K to K)
(Match L to L)
(Match M to M)



27. Connect the wires from HEAD, LEFT HAND WITH SACK, and PANTS with human sensor wires to the CONTROL BOX.

(Connect R to R)
(Connect S to S)
(Connect T to T)
(Connect U to U)




ASSEMBLY INSTRUCTIONS

28. Hook and loop fasten back of SHIRT.



29. Pull the PANTS up and hook and loop fasten around the WAIST FRAME.

Hook and loop fasten the PANTS to the SHIRT.



18. Pull the 4 TETHER lines out and secure the ground STAKES by inserting them into the ground.

Finish the ground STAKE setup by securing the METAL FRAME with inserting four additional ground STAKES in all four corners of the METAL FRAME as shown.



OPERATING INSTRUCTIONS

31. Move the switch to the ON position. Move in front of the item or make a loud sound (clap) to activate the item. Move the switch to the HUMAN ONLY position to activate the item with motion only.

Turn the item to the OFF (DEMO) position when not in use.



OPTIONAL DEMO SET UP

FOOTPAD IS NOT INCLUDED.
MUST BE PURCHASED SEPARATELY

1. Insert the cable from optional footpad into the jack labeled DEMO JACK on the CONTROL BOX.
2. Place the switch in the DEMO position to enable DEMO activation.
3. Step on the FOOTPAD to activate the scary sequence!

* Footpads are sold separately.



OPTIONAL EXTERNAL SPEAKER SET UP

EXTERNAL SPEAKER IS NOT INCLUDED.
MUST BE PURCHASED SEPARATELY.

1. Plug speaker cord into the jack labeled SPEAKER JACK located on the CONTROL BOX.
2. Use volume knob on external speaker to control volume levels.



CARE AND MAINTENANCE

- STORE IN A COOL AND DRY ENVIRONMENT.
- IN INCLEMENT WEATHER BRING ITEM INDOORS.
- SURFACE WASHABLE ONLY. DO NOT USE ANY HARSH OR ABRASIVE CLEANING AGENTS.
- DESIGNED FOR SEASONAL OPERATION ONLY.
- NOT INTENDED FOR CONSTANT OR LONG-TERM USE.
- PROPER STORAGE AND USE ARE ESSENTIAL TO THIS ITEM'S LONGEVITY.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Item will not activate.	<ul style="list-style-type: none">• 5.9V 3A adapter is not plugged in.• Switch on control box is not in the ON position.• Human sensor on pants may be blocked.	<ul style="list-style-type: none">• Check 5.9V 3A adapter is plugged in and securely inserted into the control box.• Move switch to ON position.• Move any obstructions away from the pants.
You only hear item sound but no item activation.	<ul style="list-style-type: none">• Control box wires are not connected.	<ul style="list-style-type: none">• Check that wires labeled R, S, T, U, and V are securely connected.
Item has no sound while operating.	<ul style="list-style-type: none">• Volume knob is turned all the way down.	<ul style="list-style-type: none">• Adjust volume knob to desired volume.

FCC REGULATION

FCC STATEMENT

FCC RULES: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.