



weight adjustment

The tension of the back relates to the sitter's body weight. Turn the wheel forward and the tension will be increased; turn it backward and the tension will be reduced.



seat height

Use the lever under the front of the seat on the right to adjust the seat height. Draw the lever up, then release when seat is at desired height.



synchronised sitting

Turn forward to lock synchronous back and seat movement. Turn backwards to unlock synchronous seat and back movement.



seat depth

By pressing the oblong button on the right side of the seat, you can slide the seat forward or backward.



back height & lumbar

The height of the backrest can be adjusted when the lever at the rear of the backrest is pulled out. The depth of the support is adjusted by turning the integrated handwheel on the backrest. Turning it to the right increases the supportive strength, turning it to the left reduces the strength.